

The VFT-2000 Transfer Unit is purposely designed for handling containers produced on TG and QG production machines. The gradual collection of the containers at the entrance to the transfer, along with a smooth, large radius curve and unique finger motion at the exit, ensures that bottles are transferred onto the cross conveyor accurately.


Features and Benefits

- 2 finger sizes
- · 4 finger spacing configurations
- Designed for TG or QG production
- · Unique finger retract system
- 'Quick Change' fingers
- Transfers containers from 40mm to 96mm diameter
- Adjustable top and bottom ware guides
- Spacing reduced through transfer
- · Reduced job set-up time
- Enhanced container stability
- Recommend to be used in conjunction with STK/9433L/R Independent Belt Drive or 175mm deadplate.

- · Reliable cross conveyor spacing
- Minimal spares holding
- Round containers consistent ware handling up to 1.000 BPM
- Flask production at 300-450 BPM
- Intermediate fingers from 12 fingers and above
- For optimum performance we recommend use with Sheppee Cross Conveyor (CCA) and Independent Belt Drive (IDB)
- Recommended service intervals 12 months
- · Carbon or SSB insulation







Technical Specifications

Operating speed: Up to 1000

BPM

Standard chain length: 157.5"

Standard chain pitch: 3/4" Duplex

Number of teeth on sprocket: 30


Chain movement per revolution of

drive shaft: 22.5"

Installation Details and Service Requirements

- Connection to Lincoln lubrication
- Can be driven by servo or synchronous motor drive
- Can work with all I.S. machine drive systems
- Transfer can be used in conjunction with Sheppee ITD-8200 Transfer Drive Unit.

Chain Length Data




Finger Spacing Options

	Number of Fingers	Finger Spacing	Finger Part Number *	Intermediate Finger Part Number	Container Size Limits	
	42	3 3/4"	VFT-1008-01L/R		68mm	
	35	4 1/2"	VFT-1008-02L/R		78mm	
	30	5 1/4"	VFT-1008-02L/R		92mm **	
-	21	7 1/2"	VFT-1008-03L/R	VFT-1008-P-L/R	120mm	
	15	10 1/2"	VFT-1008-03L/R	VFT-1008-P-L/R	170mm	
Special***						
	53	3"	VFT-1008-01-L/R		52mm	

^{*} For SSB (stainless steel braid) option, add "-SSB" to the end of the part number.

Contact Material

- customer to specify





Telephone assistance

Telephone assistance is available for all Sheppee International customers, according to the times given below.

Standard office hours telephone assistance Monday to Thursday 08.30 - 17.15 (GMT) Friday 08.30 - 13.00 (GMT)

Contact: **+44 1904 608999**

Email Contact: support@sheppee.com

Out of office hours Telephone Assistance Monday to Thursday 17.15 – 08.30 (GMT)

Friday 13.00 – 23.59 (GMT)

Saturday, Sunday and Public Holidays - 24 hour

Contact: +44 844 826 5421 (UK only)

+44 117 987 5421 (International)

^{**} For diameter 92mm-96mm special pusher pad required.

^{***} Special chain required of 159"



Variable and Consumable **Item Identification Chart**

Part: VFT-1008-01-L/R Size 01 Finger Assembly

Part: VFT-1008-02-L/R Size 02 Finger Assembly



Part: VFT-1008-01-L/R-75 Size 01 Tall Finger Assembly

Part: VFT-1008-02-L/R-75 Size 02 Tall Finger Assembly



Part: VFT-1013L/R Intermediate Finger



Part: HST-117-01 Size 01 Pusher Pad

Part: HST-117-03 Size 02 Pusher Pad



Part: HST-022-INV Back Pad



157.5" Chain Part: VFT-1011


159" Chain Part: VFT-1011-53



Finger Carrier Part: VFT-028




Container size limits



*For diameter 93mm-96mm special pusher pad required







T: +44 1904 608 999 F: +44 1904 608 777

E: sales@sheppee.com

V1.0